



Important for Pad Life:

When wrapping wires around pads to put them away, have the black sides out.



Important for Pad Life:

If you wrap wires around the pads when you put them away, first put 2 or more pads together with the black sides out.



If the formica faces out, wrapping the wires can permanently bend it downward in the center, making a less responsive pad. It is possible to bend the formica all the way down so it touches the hardboard. Then the switch never releases - never signaling a "jump".

Also, force from the wires can start cracks in the formica near the edges. Until it cracks too far, the pad will continue to work just fine. Just the appearance is marred.